USER MANUAL



N-EDIT MESSAGE EDITOR

INDEX

4 Inicial settings		4
4.1 Login		4
4.2 Language		4
4.3 Light mode and dark mode		5
5.1 Create a project		6
5.2 Modify project		<i>,.</i> 9
5.3 Send to N-Frota		9
6.1 Create route	<u> </u>	<i>.</i> 11
<u> </u>		
7 Panel		15
	////	
8.2 Drawing mode		18
9 Search and filters		21
10 Importing projects		22
10.1 ".xml" file		22
11 Exporting projects		25

1 Introduction

This manual aims to provide information related to Inova Sistemas Eletrônicos' electronic panels system and its message editor, so that it can be used and configured correctly, ensuring its perfect operation, aiming for total customer satisfaction.

It is important that the user read this material before using the products. Therefore, using the equipment will be a pleasant and safe experience and comprehending each step will be easily understood.

Inova Sistemas Eletrônicos, holds the rights to modifying any information on this manual without previous notice to the user.

2 Warranty

Inova Sistemas Eletrônicos Ltda offers a 1-year warranty against manufacturing defects from the equipment's purchase date. It is worth noting that the loss of equipment, charges or expenses incurred by the user as a result of incorrect use or installation, damage caused by chemical products, accidents, maintenance and/or modifications in any aspects that degrade the original product are not covered by the factory warranty without the authorization of Inova Sistemas Eletrônicos Ltda.

3 Contact and support

E-mail: tecmov@tecmov.com


Website: www.tecmov.com


Phone: +52 (55) 5395 1542 México, CDMX

MNITV13i#1_TECMOV - 05/10/23

4 Inicial settings


4.1 Login





4.2 Language


The system is featured in 4 languages: Portuguese, English, Spanish and French. It is possible to choose the language on the login screen, or after logging in. This feature is always located in the upper right corner, displaying the flag of the chosen language.






4.3 Light mode and dark mode

The system has 2 modes: light mode and dark mode. It is possible to choose the mode on the login screen, or after logging in by selecting the moon icon located in the center of the screen, below the username and password fields.



After logging in, the icon will be located in the upper right corner.





5 Project

Contains the information about the routes and messages that the itinerary will receive and display.

5.1 Create a project

To create a project, click on the "+" button, that will open a window to configurate and specify each one of the panels of the project. It is possible to have from 1 to 10 panels per project.





It is necessary to fill all the fields in order to create a project.

Name: Project name

Panel 1

Address: Sequential number responsible for identifying each project panel, unchangeable.

Model: Written on the identification label (number of lines x number of columns)

Position: Identifies where the panel will be located on the bus


Main color: Panel LED color

Prefix: Number of columns destined for the prefix area

Prefix color: Color of the prefix area LEDs

+ Add panel: Button to add more panels to the project, if necessary.

For each panel, always look for the model, prefix and color of the LED information on the identification label, located on the back of the panel.



6 - Color of LEDs:

AM - Amber LED

VD – Green LED

VM – Red LED


AZ – Blue LED


B - White LED

- 7 In case there is a prefix, identifies the quantity of columns of the prefix.
- 8 In case there is a prefix, identifies the LED colors of the prefix.

5.2 Modify project

After the project is created, it is possible to change it by clicking on the button "...", located in the right side of the project name.





Edit: To edit the project, alter the name or the information on the panel.

Duplicate: To duplicate the selected project.


Delete: To delete the selected project.


Position: Change the position which the project will be displayed in the N-Edit project column.


Send to NFrota: Send the project to N-Frota


5.3 Send to N-Frota

Project files generated in the N-Edit message editor can be sent to N-Frota quickly and conveniently. First, select the project and click on the option Send to N-Frota. Once the import process is complete, the project will be on the list of N-Frota projects with the N-Edit symbol next to it, and on N-Edit there will be a green checkmark indicating that the project has been sent and is up to date.












Project successfully updated and sent to N-Frota.



Project has been modified and not sent to N-Frota with the last change (it is necessary to send the project to N-Frota again to update it)




6 Bus route

Contains the messages that each panel will display. A project can have up to 999 routes, the name of each rout will be visible on the HMI screen.

6.1 Create route

To create a route, click on the "+" button, which will display a window for identifying and configuring each route.




It is necessary to fill all the fields in order to create a project.

Number: route number that will be visible on the HMI.

Name: route name.

Mode: Normal, Round Trip and Extra message.



There are 3 types of routes:

Normal mode: It can contain up to 10 message screens in the editor, with numbers from 1 to 999.



Round trip mode: It can contain up to 10 message screens on each column, with numbers from 1 to 999, the messages are separated and can be accessed through the directional keys on the HMI.




- Itinerary displaying messages GOING mode
- Itinerary displaying messages RETURNING mode


Extra mode: It can have up to 10 message screens on the editor, numeration is separated from the other modes, being from 11 to 150. Routes created with this mode are saved with the extra messages in the HMI. Usually intended for greeting messages, this mode is separate from the others.



6.2 Change route

After the route is created, it is possible to alter it by clicking on the "..." button, located on the right side of the route name.






Edit: To edit the route, change its name, number or mode.

Duplicate: To duplicate the selected route.

Delete: To delete the selected route.

7 Panel

This column displays all the panels added to the project and its respective sizes. It is possible to select each one of them and add the messages in the editor.




8 Editor


In this column, the screen of each panel will be created, messages written in that column will be displayed on the itinerary when the bus route is selected.

8.1 Writing messages


In the field highlighted in red, enter the text that will be displayed on the itinerary. It is necessary to write the messages on all of the project panels.



For panels that have prefix, the field for the it will be separated from the rest of the panel. Additionally, more features will be released related to the prefix area.




The editor features many options to adjust the text to the panel size in the best way possible.




8.2 Drawing mode

In this mode, it is possible to insert predefined drawings on the screen, or create a pixel-by - pixel drawing.





The drawing mode features many options to adjust the text to the panel size in the best way possible.




8.3 Simulation mode

After writing the messages, it is possible to visualize how they will be displayed on the panel, showing the screen time and transitions. Click on the simulation button to visualize it.





To increase the editor's exhibition area, click on the arrows located between the project, route and panel columns.




9 Search and filters


The search tool allows the user to find projects, routes and panels faster, by just entering the name on the corresponding search field.



The route column features a filter to search among the route modes.








10 Importing projects


It is possible to import files to N-Edit, making it easier to develop or modify new projects.


10.1 ".xml" file


For customers that are still using the former ISI message editor, it is possible to do the backup of the Project and import the file to N-Edit.

















10.2 ".xlsx" file


It is possible to import ".xlsx" files using the model provided by N-Edit. By doing so, the messages and texts will be automatically uploaded according to the table's data. When importing the file, it is necessary to inform the panel's model, recalling that after import, it is important to review the texts to make the necessary adjustments.


	A	В	С	D	E	F	G	Н	1	
1	Code	Prefix	Name	Screen text 1	Screen text 2	Screen text 3	Separating panels	Screen text 1	Screen text 2	
2	1	11	Bus Route 1	Message 1	Message 1	Message 1		Message 1	Message 1	
3	2	22	Bus Route 2	Message 2	Message 2	Message 2		Message 2	Message 2	
4	3	33	Bus Route 3	Message 3	Message 3	Message 3		Message 3	Message 3	
5	4	44	Bus Route 4	Message 4	Message 4	Message 4		Message 4	Message 4	
6										
7										


















11 Exporting projects

It is possible to export projects with the ".nedit" extension, this file will be sent to the HMI using the N-Drive app. Another alternative is to export a PDF file containing the route, messages and effects information.









Wednesday, 20 of September of 2023



Project Id: 7 Project Name: **Project**

Script Report

1 **Roteiro Normal** Panel Format Message Effect Time Effect Normal Transition 13x64 INOVA 3.00 Avarage Normal Transition 16x128 SISTEMAS Front 3.00 Avarage Normal Transition 08x80 ELETRÔNICOS 3.00 Back Avarage 2 Roteiro ida e volta Localization Panel Format Message Effect Time Effect Normal Transition 13x64 INOVA 3.00 Avarage Normal Transition INOVA 3.00 Avarage Normal Transition Front 16x128 INOVA 3.00 Avarage

